
















# WorkSimpli ASSEMBLY INSTRUCTIONS

## MODEL: PL137THALF + PL237THALF & PL139

1/2 RACETRACK / BOAT SHAPE TOP (REQUIRES BASE)

### KLIX CAM INSTRUCTIONS



















### IMPORTANT NOTE :

- Place all wooden parts on a clean, smooth surface to prevent the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Do not tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children.


































# MODEL: PL137THALF + PL237THALF

## 1/2 RACETRACK / BOAT SHAPE TOP (REQUIRES BASE)

### COMPONENTS:

FOR END BASE See Page 4		+		+			
FOR ELLIPTICAL BASE See Page 5		+		+			
FOR CUBE BASE See Page 6		+					
FOR V-LEG/U-LEG BASE See Page 7		+		+		+	
FOR V-LEG/U-LEG BASE See Page 7		+		+		+	

### HARDWARE:

INCLUDED WITH TABLE TOP	<div>A1</div>  <div>A2</div>  <div>A3</div> 
INCLUDED WITH END BASES	<div>C1</div>  <div>C2</div>  <div>C3</div>  <div>C4</div>  <div>C5</div>  <div>C6</div>  <div>C7</div>  <div>C8</div> 
INCLUDED WITH ELLIPTICAL BASES	<div>D1</div>  <div>D2</div>  <div>D3</div>  <div>D4</div>  <div>D5</div>  <div>D6</div>  <div>D7</div>  <div>D8</div> 
INCLUDED WITH CUBE BASE	<div>E1</div>  <div>E2</div>  <div>E3</div>  <div>E4</div>  <div>E5</div>  <div>E6</div> 
INCLUDED WITH V-LEG/U-LEG BASES	<div>F1</div>  <div>F2</div>  <div>F3</div>  <div>G1</div>  <div>G2</div>  <div>G3</div>  <div>H1</div> 
INCLUDED WITH SQUARE POST LEG	<div>I1</div> 


## MODEL: PL139

### RACETRACK / BOAT SHAPE CONFERENCE TABLES (REQUIRES BASE)

#### COMPONENTS:


#### Option 1

See Page 8




#### Option 2

See Page 9




#### Option 3


















































See Page 10



#### Option 4

See Page 10



HARDWARE PACK PL 139 T							
<b>A4</b>  6 Hole L-Bracket 5 Pcs	<b>A5</b>  Flat Bracket 6 Pcs	<b>A6</b>  Screw #6 x 3/8 66 Pcs					
HARDWARE PACK PL 137 T/PL 237 T							
<b>D1</b>  KD Fitting 2 Pcs	<b>D2</b>  Klix Cam 4 Pcs	<b>D3</b>  Housing Cap (Long) 4 Pcs	<b>D4</b>  6 Hole L-Bracket 6 Pcs	<b>D5</b>  Flat Bracket 2 Pcs	<b>D6</b>  Screw #6 x 3/8 48 Pcs	<b>D7</b>  Fitting-GL Screw 2 Pcs	<b>D8</b>  Wrench 1 Pc
HARDWARE PACK PL 3678 EP2							
<b>E1</b>  Cam Lock 10 Pcs	<b>E2</b>  Klix Cam 10 Pcs	<b>E3</b>  Housing Cap (Long) 6 Pcs	<b>E4</b>  Housing Cap (Short) 4 Pcs	<b>E5</b>  Adjustable Glide 4 Pcs	<b>E6</b>  6 Hole L-Bracket 4 Pcs	<b>E7</b>  Screw #6 x 3/8 24 Pcs	<b>E8</b>  M4 x 65 Allen-Key 1 Pc
HARDWARE PACK PL 389 CP1 x 2							
<b>F1</b>  Cam Lock 6 Pcs	<b>F2</b>  Klix Cam 6 Pcs	<b>F3</b>  Housing Cap (Long) 4 Pcs	<b>F4</b>  Housing Cap (Short) 2 Pcs	<b>F5</b>  Adjustable Glide 2 Pcs	<b>F6</b>  6 Hole L-Bracket 4 Pcs	<b>F7</b>  Screw #6 x 3/8 24 Pcs	<b>F8</b>  M4 x 65 Allen-Key 1 Pc
HARDWARE PACK PL 36 ELPBASEEP2							
<b>I1</b>  Cam Lock 6 Pcs	<b>I2</b>  Klix Cam 6 Pcs	<b>I3</b>  Housing Cap (Long) 6 Pcs	<b>I4</b>  Adjustable Glide 4 Pcs	<b>I5</b>  6 Hole L-Bracket 4 Pcs	<b>I6</b>  Screw #6 x 3/8 24 Pcs	<b>I7</b>  M4 x 65 Allen-Key 1 Pc	<b>I8</b>  CSK Scw M3.5 x 20MM 16 Pcs
HARDWARE PACK PL 3678 EP2							
<b>J1</b>  Cam Lock 10 Pcs	<b>J2</b>  Klix Cam 10 Pcs	<b>J3</b>  Housing Cap (Long) 6 Pcs	<b>J4</b>  Housing Cap (Short) 4 Pcs	<b>J5</b>  Adjustable Glide 4 Pcs	<b>J6</b>  6 Hole L-Bracket 4 Pcs	<b>J7</b>  Screw #6 x 3/8 24 Pcs	<b>J8</b>  M4 x 65 Allen-Key 1 Pc
HARDWARE PACK PL CUBE20							
<b>K1</b>  Cam Lock 16 Pcs	<b>K2</b>  Klix Cam 16 Pcs	<b>K3</b>  Housing Cap (Long) 16 Pcs	<b>K4</b>  JCBC Screw M6 x 40mm = 4pcs Washer = 4pcs	<b>K5</b>  Adjustable Glide 6 Pcs	<b>K6</b>  M4 x 65 Allen-Key 1 Pc		




# WorkSimpli ASSEMBLY INSTRUCTIONS

## MODEL: PL137THALF + PL237THALF

### 1/2 RACETRACK / BOAT SHAPE TOP (REQUIRES BASE)


#### ASSEMBLING TABLE WITH END PANEL BASE

1



Attach the two End Base (C) to Modesty Panel (B) by using Cam Lock (C1) and Klix Cam (C2).


2



Attach the Flat-Bracket (A2) to two Top Panel (A) as shown. Tighten Screws (A3) securely.


3

Attach the body (B&C) to Top Panel (A) by using Cam Lock (C1) and Klix Cam (C2).




Attach the L-Bracket (A4/C6) to End Base (C) and Modesty Panel (B) as shown. Tighten Screws (A6/C7) securely.

4



Screw Adjustable Glide (C5) into bottom of End Base (C).

5



Attach Housing Cap (A3/C3/C4) to all Klix Cam (A2/C2) by pushing neck through center of cam.






## MODEL: PL137THALF + PL237THALF

### 1/2 RACETRACK / BOAT SHAPE TOP (REQUIRES BASE)

#### ASSEMBLING TABLE WITH ELLIPTICAL BASE


1



Screw Adjustable Glides (D4)&(F4) into bottom of Elliptical Bases (D)&(F).

Attach metal plate to Elliptical Base (D)&(F) with included screws.


2




Attach 2 Pcs Elliptical Base (D) to Modesty Panel (B) by using Cam Lock (D1) and Klix Cam (D2).

3

Attach the Flat-Bracket (A5) to two Top Panel (A) as shown. Tighten Screws (A6) securely.



4



Attach Elliptical Base (D) to Top Panel (A) by using Screw (D8).

Attach Top Panel (A) to Modesty Panel (B) by using Cam Lock (D1) and Klix Cam (D2).

Attach the L-Bracket (A4/D5) to Elliptical Base (D) and Modesty Panel (B) and Top Panel (A) as shown. Tighten Screws (A6/C6) securely.




# ASSEMBLY INSTRUCTIONS

## MODEL: PL137THALF + PL237THALF

### 1/2 RACETRACK / BOAT SHAPE TOP (REQUIRES BASE)



#### ASSEMBLING TABLE WITH ELLIPTICAL BASE

1




Attach Cube Base (E) by using Cam Lock (E1) and Klix Cam (E2).

2




Screw Adjustable Glide (E5) into bottom of End Base (E).

3



Attach Cube Base Support (E) by using Cam Lock (E1) and Klix Cam (E2).


4



Attach the Flat-Bracket (A5) to two Top Panel (A) as shown. Tighten Screws (A6) securely.

5

Attach Top Panel (A) to Cube Base (E) by using JCBC Screw (E4) and tighten with Allen Key (E6).








## MODEL: PL137THALF + PL237THALF

### 1/2 RACETRACK / BOAT SHAPE TOP (REQUIRES BASE)

#### ASSEMBLING TABLE WITH V-LEG BASE




#### ASSEMBLING TABLE WITH V-LEG BASE + SQUARE POST LEG




## MODEL: PL139

### RACETRACK / BOAT SHAPE CONFERENCE TABLES (REQUIRES BASE)

#### OPTION 1




Attach Center Base (F) to Modesty Panel (B) by using Cam Lock (E1/F1) and Klix Cam (E2/F2). Attach Modesty Panel (C) to Center Base (F) by using Cam Lock (E1/F1) and Klix Cam (E2/F2). Attach End Base (E) to Modesty Panel (C) by using Cam Lock (E1/F1) and Klix Cam (E2/F2). Attach Top Panel (A) & Top Panel (D) to Center Base (F) & End Base (E) & Modesty Panel (B/C) by using Cam Lock (E1/F1) and Klix Cam (E2/F2).



## MODEL: PL139


### RACETRACK / BOAT SHAPE CONFERENCE TABLES (REQUIRES BASE)

#### OPTION 2



Attach the Flat-Bracket (A5/D5) to two Top Panel (D) and Top Panel (A) as shown. Tighten Screws (A6/D6) securely.

Attach Center Eleptical Base (J) to Modesty Panel (G) by using Cam Lock (J1/I1) and Klix Cam (J2/I2). Attach Modesty Panel (H) to Center Base (I) by using Cam Lock (J1/I1) and Klix Cam (J2/I2). Attach Eleptical Base (J) to Modesty Panel (H) by using Cam Lock (J1/I1) and Klix Cam (J2/I2). Attach Top Panel (A) & Top Panel (D) to Center Eleptical Base (I) & End Base (J) & Modesty Panel (G/H) by using Screw (J7/I8).



Attach the L-Bracket (A4/D4/J6/I5) from Top Panel (A/D) to Modesty Panel (G/H) and Eleptical Base (I) and Center Eleptical base (J) as shown. Tighten Screws (A6/D6/J7/I8) securely.


Attach Top Panel (A) & Top Panel (D) to Center Eleptical Base (I) & End Eleptical Base (J) & Modesty Panel (G/H) by using Screw (J7/I8).

Attach Housing Cap (A3/D3/J3/I3) to all Klix Cam (A2/D2/J2/I2) by pushing neck through center of cam.

## MODEL: PL139


### RACETRACK / BOAT SHAPE CONFERENCE TABLES (REQUIRES BASE)

#### 1 OPTION 4




Attach Cube Base (K) by using Cam Lock (K1) and Klix Cam (K2).

#### 2




Screw Adjustable Glide (K5) into bottom of End Base (K).

#### 3




Attach Cube Base Support (K) by using Cam Lock (K1) and Klix Cam (K2).

#### 4



Attach Top Panel (A) to Cube Base (K) by using JCBC Screw (K4) and tighten with Allen Key (K6).

#### 5 OPTION 3



Attach the Flat-Bracket (A6/D6) to two Top Panel (D) and Top Panel (A) as shown. Tighten Screws (A5/D5) securely.